

LEFT

RIGHT

H-36-6	6	5	4	3	2	1
Heating Elements	6kw	6kw	6kw	6kw	4kw	6kw
Volts	220	220	220	220	220	208
Thermostats (Degrees)	125	125	125	125	135	110

H-28-4	4	3	2	1
Heating Elements	5.3kw	5.3kw	6kw	6kw
Volts	208	208	220	208
Thermostats (Degrees)	125	125	135	110

H-24-4 South	4	3	2	1
Heating Elements	5.3kw	5.3kw	4kw	6kw
Volts	208	208	220	208
Thermostats (Degrees)	125	125	135	110

H-24-4	4	3	2	1
Heating Elements	6kw	6kw	4kw	6kw
Volts	220	220	220	208
Thermostats (Degrees)	125	125	135	110

H-18-4	4	3	2	1
Heating Elements	4kw	4kw	4kw	6kw
Volts	208	208	220	220
Thermostats (Degrees)	125	125	135	110

H-16-4	4	3	2	1
Heating Elements	4kw	4kw	4kw	4kw
Volts	208	208	220	220
Thermostats (Degrees)	125	125	135	110

H-16-2	2	1
Heating Elements	6kw	6kw
Volts	208	208
Thermostats (Degrees)	135	110

H-14-2	2	1
Heating Elements	6kw	6kw
Volts	240	208
Thermostats (Degrees)	135	110

H-14-2	2	1
Heating Elements	4.5kw	6kw
Volts	240	208
Thermostats (Degrees)	135	110

Tankless, Inc.
Quality, Energy Saving, Tankless Hot Water Heaters



ELECTRICIANS

To order parts,
call 1 800 826 5537

The Positions of the Elements and Thermostats are numbered from RIGHT to LEFT.

Left ----- Right

